

# KICKER®

EB141 OWNER'S MANUAL

EB141 MANUAL DEL PROPIETARIO


EB141 HANDBUCH

NOTICE D'UTILISATION EB141

# KICKER® ENGLISH VERSION

## STEREO EARBUDS

EB141 OWNER'S MANUAL



### ⚠ WARNING!


Exposure to excessive sound levels can cause permanent hearing damage.

Keep out of reach of children. The content of this package includes small parts and cords that can cause choking or strangulation.

If an earbud or earbud tip becomes lodged in the ear canal, seek professional medical assistance for its removal.

Never pull on the cord to remove the earbuds. Use a slow twisting motion to remove from ear.

### USING MEMORY FOAM INSERTS




### EB141 Earbud Specifications

Frequency Response, Hz	18-21K	Weight/Mass, oz (g)	.70 (20)
Sensitivity, dB/1mW	112	Speaker Diameter, in (mm)	.55 (14)
Nominal Impedance, ohm	32	Max Input Power, mW	5
Cord Length, in (cm)	53.15 (135)	Max Output, dB	118
Cable Type, ga (mm)	Black braided cloth cable with Kicker® Ultra Gauge Wire		
Plug Type, in (mm)	1/8 (3.5) plug with corrosion resistant nickel plating		
Magnet Material	Neodymium Iron Boron (Nd-Fe-B) Magnet		

# KICKER® VERSIÓN ESPAÑOL

## AURICULARES ESTÉREO

EB141 MANUAL DEL PROPIETARIO



### ⚠ ¡ADVERTENCIA!


La exposición a niveles sonoros excesivos puede causar daños auditivos permanentes.

Mantenga alejado de los niños. El contenido de esta caja incluye piezas pequeñas y cables que pueden causar asfixia o estrangulamiento.

Si un auricular o extremo de auricular queda atascado en el canal auditivo, busque ayuda médica profesional para quitarlo.

No tire del cable para quitarse los auriculares. Gírelos lentamente para quitarlos de los oídos.

### Uso de insertos de espuma con memoria




### EB141 Especificaciones de auricular

Respuesta en frecuencia, Hz	18-21K	Peso/Masa, oz (g)	0.70 (20)
Sensibilidad, dB/1mW	112	Diámetro del altavoz, in (mm)	0.55 (14)
Impedancia nominal, ohmios	32	Potencia máx. de entrada, mW	5
Longitud de cable, in (cm)	53.15 (135)	Salida máxima, dB	118
Tipo de cable, calibre (mm)	cable negro de tela trenzada calibre 14 (0.06) con conductor de calibre ultrafino Kicker®		
Tipo de conector, in (mm)	Conector de 1/8 (3.5) con niquelado resistente a la corrosión		
Material del imán	Imán de neodimio-hierro-boro (Nd-Fe-B)		


## STEREOOHRHÖRER

### EB141-HANDBUCH




#### Benutzung der Memory-Schaumgummieinsätze

Drücken Sie die Schaumgummieinsätze zusammen



Setzen Sie den Ohrhörer ein



Halten Sie diesen 30 Sekunden lang fest, bis der Schaumgummi sich ausgedehnt hat.

#### ⚠️ WARNUNG!

Ohrhörer können sehr hohe Schallpegel erzeugen, welche zu permanenten Hörschäden führen können.

Außerhalb der Reichweite von Kindern aufbewahren. Diese Verpackung enthält Kleinteile an denen sie ersticken und Kabel mit denen sie sich strangulieren können.

Wenn ein Ohrhörer oder ein Stöpsel im Gehörkanal feststeht, suchen Sie ärztliche Hilfe auf, um diesen zu entfernen.


Ziehen Sie zum Entfernen der Ohrhörer niemals am Kabel. Drehen Sie die Ohrhörer leicht, um sie aus dem Ohr zu entfernen.

#### EB141Ohrhörer - Technische Daten

Frequenzbereich, Hz	18 - 21 K	Gewicht, oz (g)	0,70 (20)
Empfindlichkeit, dB/1 mW	112	Lautsprecherdurchmesser (mm)	0,55 (14)
Nennimpedanz, Ohm	32	Max. Eingangsleistung, mW	5
Kabellänge, Zoll (cm)	53,15 (135)	Max. Ausgang, dB	118
Kabeltyp, ga (mm)	14 (0,06) Schwarzes, geflochtenes Leinenkabel mit Kicker® AWG Amerikanische Ultra Wire Gauge		
Stecker, Zoll (mm)	1/8 (3,5) Stecker mit korrosionsbeständiger Nickelbeschichtung		
Magnetisches Material	Neodym-Eisen-Bor (Nd-Fe-B) Magnet		


## OREILLETES STEREO

### NOTICE D'UTILISATION EB141




#### Utilisation d'inserts de mousse à mémoire

Comprimer la mousse à mémoire



Insérer l'oreillette



Maintenir 30 secondes pendant que la mousse se dilate

#### ⚠️ AVERTISSEMENT !

Une exposition à des niveaux sonores excessifs peut provoquer des dégâts permanents pour l'ouïe.

Conserver hors de portée des enfants. Ce conditionnement comprend des petites pièces et des cordons risquant d'étouffer ou d'étrangler les enfants.

Si une oreillette ou une pointe d'oreillette se bloquant dans le canal auditif, consulter une assistance médicale professionnelle pour la retirer.

Ne jamais tirer sur le cordon pour retirer les oreillettes. Effectuer un lent mouvement de torsion pour le sortir de l'oreille.

#### Spécifications de l'oreillette EB141

Réponse en fréquence, Hz	18-21K	Poids/masse, onces (g)	0,70 (20)
Sensibilité, dB/1mW	112	Diamètre de haut-parleur, pouces (mm)	0,55 (14)
Impédance nominale, ohms	32	Puissance d'entrée maximale, mW	5
Longueur de cordon, pouces (cm)	53,15 (135)	Sortie maxi, dB	118
Type de câble, GA (mm)	câble de tissu torsadé noir 14 (0,06) avec fil ultra-calibré Kicker®		
Type de fiche, pouces (mm)	Fiche 1/8 (3,5) avec placage nickel résistant à la corrosion		
Matériau d'aimant	Aimant néodyme-fer-bore (Nd-Fe-B)		

### HomeLimitedWarranty

KICKER warrants this product to be free from defects in material and workmanship under normal use for a period of ONE (1) YEAR from date of original purchase with the original receipt from an Authorized KICKER Dealer. Should service be necessary under this warranty for any reason due to manufacturing defect or malfunction during the warranty period, KICKER will repair or replace (at its discretion) the defective merchandise with equivalent merchandise at no charge. Warranty replacements may have cosmetic scratches and blemishes. Discontinued products may be replaced with more current equivalent products.

This warranty is valid only for the original purchaser and is not extended to owners of the product subsequent to the original purchaser. Any applicable implied warranties are limited in duration to a period of the express warranty as provided herein beginning with the date of the original purchase at retail, and no warranties, whether express or implied, shall apply to this product thereafter. Some states do not allow limitations on implied warranties; therefore these exclusions may not apply to you. This warranty gives you specific legal rights; however you may have other rights that vary from state to state.

#### WHAT TO DO IF YOU NEED WARRANTY OR SERVICE

Defective merchandise should be returned to your local Authorized KICKER Dealer for warranty service. Assistance in locating an Authorized Dealer can be found at [www.kicker.com](http://www.kicker.com) or by contacting KICKER directly.

If it becomes necessary for you to return defective merchandise directly to Stillwater Designs (KICKER), call the KICKER Customer Service Department at (405) 624-8510 for a Return Merchandise Authorization (RMA) number. Package all defective items in the original container or in a package that will prevent shipping damage, and return to:

**Stillwater Designs, 3100 North Husband, Stillwater, OK 74075**

The RMA number must be clearly marked on the outside of the package. Include a copy of the original receipt with the purchase date clearly visible, and a "proof-of-purchase" statement listing your name and return shipping address, the Dealer's name and invoice number, and product purchased. Warranty expiration on items without proof-of-purchase will be determined from the type of sale and manufacturing date code. Freight must be prepaid; items sent freight-collect, or COD, will be refused.

#### WHAT IS NOT COVERED?

This warranty is valid only if the product is used for the purpose for which it was designed.

It does not cover:

- o Damage due to improper use.
- o Damage due to improper installation of components or audio/video devices.
- o Subsequent damage to other components or audio/video devices.
- o Damage caused by exposure to moisture, excessive heat, chemical cleaners, and/or UV radiation.
- o Damage through negligence, misuse, flood, fire, earthquake, accident, or abuse. Repeated returns for the same damage may be considered abuse.
- o Items previously repaired or modified by any unauthorized repair facility or person.
- o Return shipping on non-defective items.
- o Products with tampered or missing barcode labels.
- o Products returned without a Return Merchandise Authorization (RMA) number.
- o Freight Damage.
- o The cost of shipping product to KICKER.
- o Service performed by anyone other than KICKER.

#### HOW LONG WILL IT TAKE?

Kicker strives to maintain a goal of 48-hour service for all electronics returns. Delays may be incurred if lack of replacement inventory or parts is encountered.

Failure to follow these steps may void your warranty. Any questions can be directed to the Kicker Customer Service Department at (405) 624-8510.

#### GARANTÍA INTERNACIONAL VersiónEspañol

Comuníquese con su concesionario o distribuidor Kicker internacional para obtener información sobre procedimientos específicos relacionados con las normas de garantía de su país.

#### INTERNATIONALE GARANTIE DeutscheVersion

Nehmen Sie mit Ihren internationalen Kicker-Fachhändler oder Vertrieb Kontakt auf, um Details über die Garantieleistungen in Ihrem Land zu erfahren.

#### GARANTIE INTERNATIONALE VersionFrançaise

Pour connaître les procédures propres à la politique de garantie de votre pays, contactez votre revendeur ou distributeur International Kicker.